


# Warming Station User Manual

MODEL NO.: WM-2F/WM-3F

## I . Illustration



1. Baffle

2. Infrared lamps

3. Warming area

4. Power Socket

5. ON/OFF

6. Lamp Controller-1

7. Lamp Controller-2

8. Temperature Control

9. Frame

## II . Technical Specification

Name	Single Lamp	Double Lamp	Triple Lamp	QuadrupleLamp
Voltage	220V	220V	220V	220V
Power	0.75KW	1KW	1.25KW	1.5KW

## III. Installation

1. The equipment should be installed by personnel with professional electrician certificate.
2. The power supply voltage should be consistent with the rated voltage of the equipment.
3. To install the leakage protection switch in front of the power socket, three pole socket to be connected with the ground.

## IV. Operation

1. Connect the power cord to a power socket.
2. Turn on the power switch. The power indicator (red) is on.
3. Turn on the temperature control and set the temperature. The heat indicator (red) is on, indicating that the heat is being heated.
4. Turn on the warming light to keep the food warm.

## V . Cleaning and precautions

1. Turn off the switch and unplug the power before cleaning.
2. Do not use corrosive cleaners.
3. Do not put the water to the equipment in order to avoid damage to the electrical, affecting the safety of electricity.

# Part List

