



**COUNTER TOP ELECTRIC
LAVA ROCK GRILL**

6E-TH40

6E-TH60

USER'S MANUAL

Thank you for purchasing and using Electric Lava Rock Grill. In order to make good use of the products and minimize unnecessary loss and damage, please read the manual book carefully before using and keep it well for future reference.

WARNING!

! The appliance is not suitable for the people who have physical, sensory or mental defects, or the people who are lack of operating knowledge or experience to use (including children).

! Any refitting and wrong installation, adjustment and maintenance can cause property loss and casualty. Please contact the supplier if you need to adjust or maintain the appliance. And all these operations should be done by authorized professionals.

! Do not put flammable liquid, gas or other flammable objects around the appliance for your safety sake.

! Make sure the using voltage coordinate with the voltage that stated on the nameplate.

! Never use hard and sharp materials to scrape the surface of body and the surface of heating element.

A. Basic Parameter

| | | |
|---------------------------------------|---------------|---------------|
| Model | 6E-TH40 | 6E-TH60 |
| Rated Voltage | 220-240V/50Hz | 220-240V/50Hz |
| Rated input power | 3.4kW | 8kW |
| Overall Dimension L×W×H mm | 400x650x540 | 600x650x540 |
| N/W (kg) | 50 | 65 |
| Cooking surface (cm) | 35x41 | 46x41 |

B. Installation

1. The accessories: It is supplied with 2 pcs grids, 2 pcs grills, and 3KG of lava rocks for 6E-TH40, and 3 pcs grids, 3 pcs grills, and 5KG of lava rocks for 6E-TH60.
2. The electrical installation of the appliance should be operated by qualified electrician. The ground connection must be fixed firmly to prevent accidental loosening.
3. The appliance should be positioned stably.
4. The supply voltage must coordinate with the using voltage of the appliance. It should be installed a general on/off switch in main line. And a leakage protective switch is recommended to fit.
5. The equipotential terminal should be connected with copper cable under the relative regulation. The size of copper cable should not be less than 2.5 mm².

Warning!

! If the appliance is close to the wall, clapboard, other kitchen equipments, and decoration board, it is recommended that these neighboring objects should be made from non-inflammable materials. Otherwise, the appliance should be separated from these objects by non-inflammable and insulation materials.

! The equipotential terminal ↓ should be connected according to the relative regulation.

C. Instruction for operation

1. Before using, make sure the supply voltage coordinate with the rated voltage of appliance and the ground connection is correct and fastened.
2. If there is abnormal situation occurred when using, please stop using appliance immediately and cut off the electric power.
3. Connected to the power, when the temperature controller knob is in figure <1>

position, the green power indicator lights; clockwise rotate the knob to figure <2> position, the orange working indicator lights, heating element is working; with the rotation degree increases, the power will increase also. When the temperature reaches the required temperature, it will automatically stop heating (at the same time the orange working indicator extinguishes), when the grill temperature drops, it will automatically heat again (at the same time the orange working indicator lights). It will be a repeated cycle in order to keep the grill temperature at the desired temperature; when rotating the knob to Figure <3> position, the heating element will work continuously; continue to clockwise rotate the knob to "O" position, and the appliance will stop working. If anti-clockwise rotate the knob, vice versa.




Figure <1>




Figure <2>




Figure <3>

4. The user can set the temperature according to the different types of food.
5. After finishing work, turn the knob to figure <1> position, unplug the plug, and then cut off the power supply.
- 6.

D. Cleaning and maintenance

1. Cut off the power supply before cleaning or maintaining the equipment in case of any electric shock accidents.
2. Before cleaning or maintaining the appliance, please wait till the appliance cools down.
3. Do not use wet towel with non-corrosive cleanser to clean the appliance. Directly wash with water is not permitted in case of any damage of the electric component of the appliance.

Warning!

Never use a water hose or pressurized steam cleaning equipment to clean this appliance.

E. Troubleshooting

Before maintaining the appliance, please unplug the appliance and make sure the power is cut off.

| Symptoms | Causes | Solution |
|---|---|--|
| 1. Turn on the switch, but the power indicator is not on. | 1. Electric connection has problem. | 1. Check the electric connection. |
| 2. The orange indicator lights. The appliance is over-temperature. | 1. The temperature controller knob was turn to figure <3> position. | 1. Adjust the appropriate position of the temperature controller knob. |
| 3. The appliance is operating normally, but the orange indicator is not on. | 1. Indicator is burn out. | 1. Replace a new one. |

Aforementioned troubles are just for reference. If any fault occurs, please stop using, and inform the professional technicians to check and repair.

ADEXA DIRECT LIMITED

Unit 1 Swift Point, Cosford Lane, Swift Valley Industrial Estate, Rugby, CV21 1QN, UK

T:+44 1788 222 410

service@adexa.co.uk

www.adexa.co.uk



EC Declaration of Conformity

Adexa Direct Limited declares that:

Equipment Type: Electric grill

Model: 6E-TH40, 6E-TH60

Imported By: ADEXA DIRECT LIMITED
Unit 1 Swift Point, Cosford Lane, Swift Valley Industrial Estate,
Rugby, CV21 1QN, UK

Brand: ADEXA

Application of Council Directive(s): EMC 2014/30/EU
LVD 2014/35/EU

Standards:

EN 55014-1:2017+A11:2020

EN IEC 61000-3-2:2019

EN IEC 61000-3-3:2013+A1:2019

EN 55014-2: 2015

EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A2:2019+A14:2019

EN 60335-2-38:2003+A1:2008

EN 62233:2008

I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s).

Date: 15.10.2021

Signature:

Full Name: Hakan Baykal

Position: Purchase Manager

ADEXA DIRECT LIMITED

Unit 1 Swift Point, Cosford Lane, Swift Valley Industrial Estate, Rugby, CV21 1QN, UK
T:+44 1788 222 410 service@adexa.co.uk www.adexa.co.uk



Declaration of Conformity

Adexa Direct Limited declares that:

Equipment Type: Electric grill

Model: 6E-TH40, 6E-TH60

Imported By: ADEXA DIRECT LIMITED
Unit 1 Swift Point, Cosford Lane, Swift Valley Industrial Estate,
Rugby, CV21 1QN, UK

Brand: ADEXA

Application of Council Directive(s): Electromagnetic Compatibility Regulations 2016 and Electrical Equipment(Safety) Regulations 2016 by UK legislation

Standards:

- BS EN 55014-1:2017+A11:2020
- BS EN IEC 61000-3-2:2019
- BS EN IEC 61000-3-3:2013+A1:2019
- BS EN 55014-2: 2015
- BS EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A2:2019+A14:2019
- BS EN 60335-2-38:2003+A1:2008
- BS EN 62233:2008

I, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s) and Standard(s).

Date: 23.8.2021

Signature: 

Full Name: Hakan Baykal

Position: Purchase Manager